

ADDENDUM FOR THE 889108 USER GUIDE

HEAD PLATE AND WEIGHT PLATE ASSEMBLY INSTRUCTIONS




FIGURE 1

- Slide the WEIGHT PLATE SHAFT thru the hole in the HEAD PLATE and lock in place using one 3/4" E-RING as shown in FIGURE 1
- Snap two WEIGHT PLATE BUSHINGS into the top of all twenty WEIGHT PLATES as shown in FIGURE 1.